



NetterVibration

Operating instructions for
high frequency electric external
vibrators series NEG/NEH



Feb. 2026
No. 1993E
Page 1/33

These operating instructions apply to:

NEG 100770

NEG 1001000

NEG 1001090

NEG 1001140

NEG 1001400

NEG 1001540

NEG 1001800

NEG 1002020

NEG 1002500 LR

NEG 1003300 LR

NEH 100600

NEH 1001140

NEH 1001140 HD

NEH 1001540

NEH 1002020

NEH 1002000 HD



Contents

1	General information	3
2	Safety	6
3	Technical data	9
4	Design and function	12
5	Transport and storage	13
6	Installation	14
7	Start-up and operation	18
8	Maintenance and servicing	24
9	Troubleshooting	29
10	Spare parts and accessories	31
11	Disposal	32
12	Annex	33

Scope of delivery

Please refer to the delivery note for the scope of delivery.
Check the packaging for possible transport damage. In the event of damage to the packaging, check the contents for completeness and possible damage. Inform the carrier in the case of damage.

Designation

The high frequency electric external vibrators of the series NEG and NEH are hereafter referred to as "NEG/NEH".

Version of document

Document no.	1993E
Version no.	3
Date of issue	Feb. 2026

1 General information

Use and storage	Before installing the NEG/NEH read these instructions carefully. It is the basis for any action when dealing with the NEG/NEH, and may be used for training purposes. The instructions should be subsequently stored at the operation site.
Target group	The target group for these instructions is technical staff, who have basic knowledge in mechanics and electrics. Only complying technical staff may work on the NEG/NEH. The NEG/NEH may only be installed, put into operation, maintained, troubleshot and disassembled by persons authorised by the operator.
Copyright	This documentation is protected by copyright. NetterVibration reserves all rights such as translations, reprinting and reproduction of the instructions, as well as parts thereof.
Limitation of liability	All technical information, data and instructions for installation, operation and maintenance in these instructions are based on the latest information available at the time of printing and take our past experience to the best of our knowledge into account. No claims can be derived from the information, illustrations and descriptions in these operating instructions. The manufacturer does not assume liability for damages resulting from: • failure to observe the instructions, • improper use, • unauthorised repairs, • technical modifications, • use of non-permissible spare parts. Translations are made to the best of our knowledge. NetterVibration does not assume liability for translation errors, even if the translation was made by us or on our behalf. Only the original German text remains binding.
Directives observed	The high frequency electric external vibrators of the series NEG and NEH comply with the following directives: • EC Machinery Directive 2006/42/EG, • Supply of Machinery (Safety) Regulations 2008 (UK), • Electromagnetic Compatibility Directive 2014/30/EU, • Electromagnetic Compatibility Regulations 2016 (UK), • Low Voltage Directive 2014/35/EU, • Electrical Equipment (Safety) Regulations 2016 (UK). The main standards observed are indicated in the declaration of conformity.

**Instruction
and warning
symbols**

The following instruction and warning symbols are used in these instructions:

**Personal
injuries**

⚠ DANGER	
	indicates an immediate danger. Disregard of this notice will result in death or severe personal injuries.

⚠ WARNING	
	indicates a potential danger. Disregard of this notice can result in death or severe personal injuries.

⚠ CAUTION	
	indicates a potentially dangerous situation. Disregard of this notice can result in minor or moderate personal injuries.

**Material
damages**

NOTICE	
indicates potential material damage. Disregard of this notice can result in material damage.	

Notes

IMPORTANT	
indicates actions, methods or notes that are not relative to safety, e.g. useful information and tips.	
	Environmentally safe disposal indicates the obligation of environmentally safe disposal.

**Type
designations**

Explanations of abbreviations in the type designation:

XXX YYYZZZZ-WWW

- XXX** indicates if the vibrator type has a housing foot:
- **NEG** type with housing foot
 - **NEH** type without housing foot (to attach with clamping device NVH)
- YYY** 100 signifies that the NEG/NEH is a high frequency electric external vibrators
- ZZZZ** indicates the centrifugal force in daN (Decanewton).
- WWW** indicates special features:
- **K** 130 °C PTC thermistor installed
 - **K2** 120 °C PTC thermistor installed
 - **TS** 130 °C thermal protector with a normally closed (NC) switching contact
 - **TS2** 120 °C thermal protector with a normally closed (NC) switching contact
 - **H** 200 - 240 V anti-condensation heater 0 - 50 W
 - **H110** 100 - 120 V anti-condensation heater 0 - 50 W
 - **HD** Fully encapsulated stator (heavy duty) and housing made of spheroidal graphite cast iron
 - **LR** Fan wheel (for cooling)

2 Safety

Intended use

The NEG/NEH are intended for generating circular vibrations.

General applications are: loosening, conveying, sorting, compacting, separating bulk materials and reducing friction. NEG/NEH are used for emptying bunkers, as drives for conveyor troughs, sieves and vibrating tables.

The NEG/NEH are designed for installation in machines and may only be put into operation, if it has been assured that the complete machine complies with the regulations of the Machinery Directive (EU) / Machinery Regulations (UK).

Any other use is considered improper.

Qualification of qualified personnel

Installation, commissioning, maintenance and troubleshooting of the NEG/NEH may only be performed by authorised qualified personnel, who have basic knowledge in mechanics and electrics.

All handling of the NEG/NEH is the responsibility of the operator.

Liability

IMPORTANT

NetterVibration assumes no liability for personal injuries and material damages if technical changes to the product were made or the notices and regulations in these instructions were not observed.

High voltage

⚠ DANGER

Risk of electric shock due to high voltage

An electric shock leads to serious injuries or even death.

- Observe the permissible protection class and earthing. The NEG/NEH may only be operated with the correct connection of the protective conductor.
- Perform all work only with insulated tools suitable for the application.
- All work on the system may only be carried out in a volt-free state.
- Never open the terminal box cover when voltage is applied.
- Never loosen or remove paint-sealed screws.
- Never touch or remove safety covers.
- Protect the NEG/NEH against falling parts during all work. Metal parts can cause a short circuit within the NEG/NEH.

Safety rules

DANGER

Electric shock

An electric shock will result in serious injury or even death. The NEG/NEH must be free of voltage during assembly, start-up, maintenance and troubleshooting.

Observe the following five safety rules:

1. Disconnect the NEG/NEH from the mains supply.
2. Secure the NEG/NEH against re-activation.
3. Establish that the NEG/NEH has no voltage.
4. Earth and short-circuit the power supply of the NEG/NEH.
5. Cover adjacent live parts or fence them off.

Falling parts

WARNING

Falling parts

The NEG/NEH or parts of the construction can come loose due to vibration. Falling parts can lead to severe personal injuries.

- For mounting the NEH use only the bracket NVH 1 or NVH 4 (depending on the NEH-type).
- Use only suitable fastening screws and safety washer to attach the NEG.
For attachment *NetterVibration* recommends using fastening kits NBS.
- Check the fastening screws after one hour of operation and thereafter regularly (generally monthly).
- Retighten the fastening screws, if necessary. Use a torque wrench and tighten the screws crosswise.
- In critical installation situations suitable securing is mandatory.

Heavy parts

WARNING

Risk of injury while handling heavy parts

Risk of serious injury due to weight during transport and installation of the NEG/NEH.

- Observe the weight information in chap. Technical data, starting on page 9.
- Only qualified personnel may transport and install the NEG/NEH.
- Use suitable load handling devices and slinging equipment.
- Wear suitable personal protective equipment.

**Frequency
and unbalance
settings**
⚠ WARNING
Risk of injury and machine damage due to incorrect frequency and unbalance settings

There is a risk of serious bodily injury due to uncontrolled machine movements. Incorrect frequency and unbalance settings on the vibrators can cause severe damage to the vibrators as well as the machine.

- The vibrators may only be operated with the maximum permissible frequency/unbalance combination.
- When changing the frequency and unbalance settings of the vibrators, observe the information on the type plate as well as the table for frequency/unbalance setting on page 20.
- Switch off the NEG/NEH immediately if you notice any irregularities in its operation. Eliminate the fault before switching on again.

**Rotating
Unbalances**
⚠ WARNING
Risk of injury due to rotating unbalances

During operation of the NEG/NEH without unbalance covers there is risk of injury due to rotating unbalances.

- Operate the NEG/NEH only with mounted unbalance covers.

Hot surfaces
⚠ CAUTION
Risk of burns due to hot surfaces

NEG/NEH can strongly heat up during operation. Direct contact may cause burns.

- Do not touch the NEG/NEH or the cable near the cable gland during operation or shortly after being switched off.
- Only operate the vibrators within the permissible ambient temperature, according to chap. Technical data, starting on page 9.


3 Technical data

Permissible operating conditions

Nominal voltage, nominal frequency	The main voltage and the main frequency must comply with the nominal voltage and nominal frequency indicated on the type plate. Permissible Voltage deviation: $\pm 5\%$ Permissible frequency deviation: $\pm 2\%$ Possible power supply with: • fixed voltage and frequency or • frequency converter Frequency changes and unbalance settings influence the centrifugal force. During operation, the maximum permissible centrifugal force (according to the type plate) must not be exceeded). The compliance with the electromagnetic compatibility directive 2014/30/EU has to be ensured.
Rotary speed ranges	2-pole: 6000 rpm at 100 Hz 4-pole: 6000 rpm at 200 Hz
Permissible ambient temperature*	$-20\text{ }^{\circ}\text{C}$ to $40\text{ }^{\circ}\text{C}$ The maximum ambient temperature specified on the type plate must not be exceeded. These values are valid for operation with an ON-period of 100 %. For the following operation modes special requirements apply: • cycled operation or • frequency-controlled operation or • synchronous operation. These must be clarified with NetterVibration on a case-by-case basis.
Sound level	Depending on type $\leq 70\text{ dB(A)}$. The sound level is determined to a great extent by the surface upon which the NEG/NEH is mounted (e.g. sheet metal). The sound level will be amplified by non-silenced sheet metal.

* Higher temperatures are only possible after consultation with and written approval from the application technicians of **NetterVibration**.

Type plate



		1	Type designation
2	Nominal voltage	2	Nominal voltage
3	Current	3	Current
4	Phases / capacity	4	Phases / capacity
5	Power factor	5	Power factor
6	Year of manufacture	6	Year of manufacture
7	Serial number	7	Serial number
8	Max. ambient temperature	8	Max. ambient temperature
9	Insulation class / degree of protection	9	Insulation class / degree of protection
10	Power output	10	Power output
11	Power input	11	Power input
12	Rotary speed / Nominal frequency	12	Rotary speed / Nominal frequency
13	Centrifugal force	13	Centrifugal force
14	Duty cycle	14	Duty cycle

The values can be found on the type plate. The type plate is located on the housing.

For detailed technical data please refer to the brochure of the NEG/NEH.

Deviating customer-specific type plates (special designs) are possible.

Brackets for NEH



Type	A [mm]	D [mm]	Weight [kg]
NVH 1	180	94	3.5
NVH 4	240	90	4.5

NEH 100600

have to be used with the bracket NVH 1.

All other types of NEH

have to be used with the bracket NVH 4.

Tightening torques

Screws as supplied, without additional lubrication. Always use a torque wrench and tighten the screws crosswise. **NetterVibration** recommends the following tightening torques [Nm].

Fastening screws and nuts, steel Property class 8.8*:

M4	M5	M6	M8	M10	M12	M16	M18	M20	M22	M24
-	-	10	25	50	87	210	-	411	559	711

* coefficient of sliding friction 0.14

Fastening screws for XS-unbalances, steel, Property class 12.9**:

M4	M5	M6	M8	M10	M12	M16	M18	M20	M22	M24
-	-	-	42	83	146	360	-	740	970	1225

** coefficient of sliding friction 0.15

Fastening screws and nuts, stainless steel:

M4	M5	M6	M8	M10	M12	M16	M18	M20	M22	M24
-	-	8,8	21,4	44	74	183	-	-	-	-

Terminal plate nuts, steel:

M4	M5	M6	M8	M10	M12	M16	M18	M20	M22	M24
1,2	2,0	3,0	6,5	13,5	-	-	-	-	-	-

Nut of the bracket NVH:

M4	M5	M6	M8	M10	M12	M16	M18	M20	M22	M24
-	-	-	-	-	-	-	NVH1: 200	-	-	NVH4: 300

Locking nuts (Pos. 21) see page 26:


M13x1	M15x1	M20x1	M25x1,5	M30x2	M45x1,5
30	50	100	170	340	500

4 Design and function

Design

Example: NEG 1001140

Example: NEH 1002020



No.	Element	Function
1	Housing	Contains and protects the components of the NEG/NEH.
2	Unbalance covers	Protect against grabbing into the unbalances.
3	Housing foot (only for NEG)	Attach the NEG to the mounting surface.
4	Type plate	Shows model specific information and data.
5	Terminal box	Contains the electrical connections.
6	Cable gland (depending on type).	Connect the NEG/NEH.
7	Retaining cam (only for NEH)	Attach the NEH to the bracket NVH 1/NVH 4 (depending on type).

Function

The high frequency electric external vibrators of the series NEG and NEH are asynchronous motors with adjustable weights (unbalances) mounted on their shaft ends.

The NEG/NEH generate circular vibrations, that means the vibrations act in all directions of a plane.

The frequency can be controlled continuously with the help of frequency converters.

The centrifugal force can be changed by adjustment of the unbalances.

5 Transport and storage




Observe the safety instructions in chap. Safety, starting on page 6.

Weights and dimensions can be found in the NEG/NEH brochure.

Transport conditions

When transporting the NEG/NEH, ensure that the NEG/NEH is not subjected to strong impacts or vibrations that could damage the bearings.



Please observe the following notes:

- Use only the transport eyelet (1) for lifting the NEG/NEH. If the vibrator is fitted with two transport eyelets, both must be used for lifting.
- The pulling direction must not exceed 45°.
- Lifting tools are of the usual kind such as a pulley or a crane. When moving loads, use suitable steel cables or hoisting slings which are sufficiently dimensioned for these weights.
- Handle the NEG/NEH very carefully during transport.

Packaging

The NEG/NEH are packed ready for installation.

The packaging protects the NEG/NEH from transport damage. The packaging material has been selected from an environmentally safe and technically disposable point of view and is therefore recyclable.

The return of packaging to the material cycle conserves raw materials and reduces the amount of waste.

Storage

- Store the NEG/NEH in a dry and clean environment.
- The permissible storage temperature is between +5 °C and +40 °C.
- The permissible relative humidity is max. 60 %.
- An inspection at **NetterVibration** is mandatory after a storage period of 2 years.
- Do not store the NEG/NEH outdoors. The electrical components are not protected against corrosion.

6 Installation



Observe the safety instructions in chap. Safety, starting on page 6.

Weights and dimensions can be found in the NEG/NEH brochure.

Fastening

The NEG/NEH can be operated in any position.

1. **Notice:** The feet of the NEG must lie completely on the surface so that there is no tension in the housing when tightening the fastening screw/screws, which could cause mechanical damage.
For NEH the bracket NVH 1 / NVH 4 must be welded over the entire surface of the structure to be vibrated.
The mounting surface has to be flat (for NEG: ± 0.1 mm flatness), and clean with no paint residues or burn-ins.



2. Fastening depending on vibrator type:
 - Mount the NEG on the mounting surface using fastening screws of strength category 8.8 (DIN 931 or 933). The fastening screws must be secured with suitable securing devices and checked or retightened at regular intervals (usually monthly). **NetterVibration** recommends the use of NBS fastening kits.
 - Mount the NEH onto the bracket NVH 1 / NVH 4 with the supplied nut.

Use a torque wrench and tighten the screws crosswise. Observe the recommended values for bolt sizes and tightening torques in chap. Technical data, from page 9. Higher tightening torques can cause the screws/nuts to break or the threads to tear out.

Warning: Improper screw connections can cause the NEG/NEH to loosen due to vibration and cause serious personal injury and damage to property.

3. In critical installation situations, use an additional safety device to prevent falling, e.g. the NSE steel cable. Use the steel cable clamps to adjust the steel cable to the shortest possible length. The steel cable must always be tensioned.




Electrical connection

The following requirements and conditions must be met to connect the NEG/NEH electrically:

- The permissible operating conditions must be met. Please refer to chap. Technical data, page 9 for operating conditions.

- A suitable overload protection (1) must be pre-connected to each vibrator. The motor protection switches must be interlocked with each other in pairs, so that in the event of a motor failure, the power supply from both motors is interrupted at the same time in order not to cause uncontrolled vibrations which can damage the system.




- Only suitable, flexible supply cables must be used for connecting the NEG/NEH. The conductors in the supply cable for the connection of the NEG/NEH to the mains must be temperature-resistant and have a sufficiently large cross-section, which is adapted to the cable length used.

When selecting the connection cables, consider that the cables are mechanically stressed by vibration. Recommended cable types for mains operation at 400 V, in potentially non-explosive atmosphere: rubber hose line H07 RN-F or oil flex cable 110 CY.


For other voltages or other ambient conditions, the cables must be adapted to the respective conditions and designed accordingly.

- All electrical cables must be carefully laid and must be protected from high temperatures, lubricants and sharp edges. Care must be taken to ensure that the cables are not chafed through by vibrating parts. The correct condition of the electrical cables with their plugs must be checked at regular intervals (usually every six months). Detected errors are to be eliminated immediately.
- The cable fastening must be provided in close vicinity of the cable entrance.
- The electrical parameters U, I, P on the type plate must be observed.
- Tighten terminal plate nuts with prescribed torque, see chap. Technical data, starting on page 9. Remember to put the safety washer between the ring and the nut and the vibration-damping insert back.
- The wire ends must be fitted with suitable insulated cable lugs, in order to prevent the strands from splaying.



Connection schemes

Open the terminal box to connect the vibrators according to the type plate as follows:






- 1 Earthing terminal for protective conductor (green-yellow)
- 2 PTC-Thermistor connection (depending on the vibrator-type)

Connect the NEG/NEH in accordance with the information on the type plate and the following connection schemes and connection data.

The green-yellow protective conductor must only be connected to the earthing terminal.

Connection schemes

3-phase current	
Smaller voltage = delta connection	Higher voltage = star connection
	
Connection without bridge	
	1: Earth terminal for protective conductor 2: PTC-Thermistor connection (depending on type)

**Connection
data**
Connection data NEG

Type	Connection data	
NEG 100770	230 V / 100 Hz = delta connection	400 V / 100 Hz = star connection
NEG 1001140		
NEG 1001540		
NEG 1001800		
NEG 1002020		
NEG 1003300 LR		
NEG 1001000	42 V / 200 Hz = without bridge	250 V / 200 Hz = without bridge
NEG 1001090	42 V / 200 Hz = delta connection	
NEG 1001400	42 V / 200 Hz = without bridge 110 V / 200 Hz = without bridge 250 V / 200 Hz = without bridge	400 V / 200 Hz = star connection
NEG 1002500 LR	42 V / 100 Hz = delta connection	400 V / 100 Hz = delta connection

Connection data NEH

Type	Connection data	
NEH 100600	230 V / 100 Hz = delta connection 400 V / 100 Hz = delta connection 42 V / 200 Hz = delta connection	250 V / 200 Hz = without bridge
NEH 1001140		
NEH 1001140 HD		
NEH 1001540	42 V / 200 Hz = delta connection	
NEH 1002020	42 V / 100 Hz = delta connection	400 V / 100 Hz = delta connection
NEH 1002000 HD		

7 Start-up and operation



Observe the safety instructions in chap. Safety, starting on page 6.

Permissible operating conditions

Please refer to chap. Technical data, page 9 for permissible operating conditions.

Regulations

- When commissioning the NEG/NEH, the rules and regulations of the local associations for electrical engineering (e.g. VDE) and the valid accident prevention regulations must be observed.
- The NEG/NEH must always be switched on and off at the main switch.
- The NEG/NEH must not be operated without the covers for the unbalances. The rotating unbalances cause a risk of injury.
- On initial start-up, the current consumption must be measured individually in all three phases and must correspond to the specifications on the type plate.
- The terminal box cover must never be opened in the presence of voltage.

Measures

Carry out the following measures before start-up:

1. Check that the NEG/NEH have been mounted correctly and are in perfect condition.
2. Check that the NEG/NEH have been properly connected and earthed.
3. Check that the cables are undamaged and laid according to the known regulations and standards.
4. Check that all permissible operating conditions have been observed.
5. Check that all protective measures on the system have been observed.
6. Eliminate possible errors before start-up.
7. Screw connections must be checked and, if necessary, retightened after 1 h operating time (after initial start-up) and thereafter regularly (generally monthly). Observe the recommended values for screw sizes and tightening torques, see chap. Technical data, starting on page 9.

Power supply

Standard network forms are TN and TT networks with an earthed star point, as in Germany. Depending on the NEG/NEH-type, suitable frequency and voltage transformers must be provided for operation. **NetterVibration** recommends the use of FSW or NFC.

For overseas countries, also for countries within the EU, the mains voltage, the network configuration and the directives applicable there must also be observed. In the case of deviations, the country, the standards, the environmental conditions, as well as possible special features in the order, must be agreed on in writing. If the NEG/NEH are operated and/or powered by another network configuration unknown to us, the guarantee expires completely and immediately.

Supply line connection

The supply line must be protected according to the cross-section and the nominal power of the NEG/NEH. The short circuit strength of this fuse should be 25 kA.

NetterVibration recommends a three-phase tripping (e. g. Schneider Electric GV2 L, Tesys Model U oder Compact NS).

Operating with frequency converter

When operating the NEG/NEH with a frequency converter, compliance with the Electromagnetic Compatibility Directive (Electromagnetic Compatibility Regulations in UK) must be ensured.

If the speed is controlled with a frequency converter, the maximum centrifugal force (according to the type plate and the table, page 20) must not be exceeded.


NEG/NEH must be adapted to your application by adjusting the unbalances. You can directly influence the vibration amplitude, centrifugal force and current consumption.

Adjustment of unbalances

For all NEG/NEH there is the possibility of unbalance adjustment to directly influence vibration amplitude, centrifugal force and current consumption.

The unbalance covers are supplied with stickers showing the current unbalance setting in %.

Notice: The unbalances may only be set mirror-symmetrically!

**Procedure:**

1. Switch off the NEG/NEH at the main switch, secure against unintentional starting and ensure that there is no voltage.
2. Loosen both unbalance covers.
3. Loosen the locking nuts or locking screws.
4. Bring the unbalances to the desired setting according to the following descriptions for the various unbalance discs. Note the mirror-symmetrical setting.
5. Retighten the locking nuts or locking screws. Observe the recommended tightening torques, see chap. Technical data, from page 9
6. Fasten both covers for the unbalances.

Number of unbalances

The table shows the number and type of unbalances, depending on the voltage and frequency:


Type	Number per side, unbalance type and setting			
	230 V / 100 Hz 400 V / 100 Hz	42 V / 200 Hz	250 V / 200 Hz	110 V / 100 Hz
NEG 100770	4x XLs Setting: 17 % max. permitted: 25 %	--	--	--
NEG 1001000	--	7x XL Setting: 100 % max. permitted: 100 %	7x XL Setting: 100 % max. permitted: 100 %	--
NEG 1001090	--	4x XLs max. permitted: 100 %	--	--
NEG 1001140	6x XLs Setting: 17 % max. permitted: 25 %	--	--	--
NEG 1001400*	10x XL Setting: 100 % max. permitted: 100 %	10x XL Setting: 100 % max. permitted: 100 %	10x XL Setting: 100 % max. permitted: 100 %	10x XL Setting: 100 % max. permitted: 100 %
NEG 1001540	6x XLs Setting: 17 % max. permitted: 25 %	--	--	--
NEG 1001800	7x XLs Setting: 22 % max. permitted: 25 %	--	--	--
NEG 1002020	8x XLs Setting: 17 % max. permitted: 25 %	--	--	--
NEG 1002500 LR	3x XLs Setting: 87 % max. permitted: 87 %	3x XLs Setting: 87 % max. permitted: 87 %	--	--
NEG 1003300 LR	2x special discs max. permitted: 100 %	--	--	--
NEH 100600	3x XLs Setting: 100 % max. permitted: 100 %	3x XLs Setting: 100 % max. permitted: 100 %	3x XLs Setting: 100 % max. permitted: 100 %	--
NEH 1001140, NEH 1001140 HD	4x XLs max. permitted: 100 %	4x XLs max. permitted: 100 %	4x XLs max. permitted: 100 %	--

Unbalances type XLs

The centrifugal force is adjustable with the unbalance discs (lamella) type XLs. Adjustment of the unbalances is carried out according to a scale disc or the supplementary sheet in the terminal box of the NEG/NEH.

By rotating the outer, adjustable unbalance disc(s) to another position, the percentage of the centrifugal force changes as shown in the illustration below. The grid position is defined by position pins.

Settings:



Settings	Unbalance per side		Type	
	fixed	adjustable		
1	1	1	NEG 1003300 LR	
	2	2	NEG 100770	NEG 1001090
			NEH 1001140 NEH 1001140 HD	
			NEG 1001140	NEG 1001540
	4	4	NEG 1002020	
2	2	1	NEG 1002500 LR	
			NEH 100600	
3	3	2	NEH 1002020	NEH 1002000 HD
4	4	3	NEG 1001800	
5	5	4	NEH 1001540	

Example:

NEH 100600 has a total of 6 unbalance discs (3 discs per side: 2 fixed, 1 adjustable). If a centrifugal force of 88 % is desired, the adjustable unbalance discs are rotated anticlockwise on both sides into the fourth grid position.

centrifugal force 100 %



centrifugal force 88 %



8 Maintenance and servicing



Observe the safety instructions in chap. Safety, starting on page 6.

Technical data Information regarding tightening torques for screws and nuts can be found in chap. Technical data, starting on page 9.

Expertise and regulations Maintenance and servicing of the vibrators may only be performed by regularly trained, authorised and qualified personnel. Work on the electrical system may only be carried out by a qualified electrician. The qualified personnel has to work exclusively with tools suitable for the application. In the case of unauthorised intervention in the NEG/NEH there is no longer any warranty claim.

Before all maintenance and servicing work the NEG/NEH must be safely disconnected from the electrical mains. The procedure is as follows:

1. Switch off NEG/NEH.
2. Secure against unintentional switching on.
3. Determine that NEG/NEH are voltage free.
4. Earth and short-circuit.
5. Cover and fence off neighbouring live parts.

Maintenance plan Maintenance of the NEG/NEH must be carried out as follows:

Interval	Action
If required (depending on operating conditions)	Clean the NEG/NEH regularly with a wet cloth to remove dust deposits.
After one hour operation after initial start-up	Check screw connections and retighten if necessary.
Every 100 operating hours	NEG: Replace the grease of the bearings completely, with grease of the type KLUEBER Isoflex NBU 15.
Monthly	Check screw connections and retighten if necessary.
	Check bearings and replace the grease if necessary, see section "Lubrication". Damaged bearings or bearings whose service life has been reached, must be replaced immediately.
	Check cable supply line.
Every 6 month	Check proper condition of connecting cables and plugs.
Every 2 years	Replace O-rings and plastic seals.
At least every 4 years	Check proper condition of electrical systems and stationary electrical equipment.

Other maintenance and repair work are to be carried out exclusively by **NetterVibration**.

Notes on lubrication

NEG/NEH with ball bearings are lubricated for their service life (permanent lubrication [DS*]).

NEG with roller bearings are lubricated with the grease of the type KLUEBER Staburags NBU 8 EP. Depending on the speeds and operating conditions, the grease of these bearings must be completely renewed at the specified intervals.

The lubrication intervals must be considerably shortened under more difficult operating conditions.

Lubrication / bearing life NEG/NEH

Type of lubrication of the bearings and bearing service life:

Type NEG	Lubrication / quantity [g]	Bearing-life [h]
100770	DS*	4480
1001000	DS*	5000
1001090	DS*	1400
1001140	12	2450
1001400	DS*	5000
1001540	16	3080
1001800	16	1870
1002020	30	5600
1002500 LR	16	640
1003300 LR	16	250


Type NEH	Lubrication / quantity [g]	Bearing-life [h]
100600	DS*	250
1001140	DS*	1400
1001140 HD	DS*	1400
1001540	DS*	470
1002020	DS*	230
1002000 HD	DS*	230

*DS = permanent lubrication


Lubrication or replace- ment of bearings

The specified item numbers refer to the spare parts list.
Overview of the different types of construction:

NEG 100770, NEG 1001000, NEG 1001140, NEG 1001400, NEG 1001540, NEG 1001800, NEG 1002020




NEG 1001090



This exploded view diagram illustrates the assembly of a motor. The main components are labeled with numbers 1 through 59. The diagram shows the motor housing (1), the motor frame (2), the motor shaft (7), the motor fan (23), the motor fan guard (24), the motor fan mounting bracket (25), the motor fan mounting bracket (26), the motor fan mounting bracket (27), the motor fan mounting bracket (28), the motor fan mounting bracket (29), the motor fan mounting bracket (30), the motor fan mounting bracket (31), the motor fan mounting bracket (32), the motor fan mounting bracket (33), the motor fan mounting bracket (34), the motor fan mounting bracket (35), the motor fan mounting bracket (36), the motor fan mounting bracket (37), the motor fan mounting bracket (38), the motor fan mounting bracket (39), the motor fan mounting bracket (40), the motor fan mounting bracket (41), the motor fan mounting bracket (42), the motor fan mounting bracket (43), the motor fan mounting bracket (44), the motor fan mounting bracket (45), the motor fan mounting bracket (46), the motor fan mounting bracket (47), the motor fan mounting bracket (48), the motor fan mounting bracket (49), the motor fan mounting bracket (50), the motor fan mounting bracket (51), the motor fan mounting bracket (52), the motor fan mounting bracket (53), the motor fan mounting bracket (54), the motor fan mounting bracket (55), the motor fan mounting bracket (56), the motor fan mounting bracket (57), the motor fan mounting bracket (58), and the motor fan mounting bracket (59).

[illegible]


NEH 100600

**Procedure:**

1. Switch off NEG/NEH, secure against switching on again and ensure that it is volt-free.
2. Loosen screw (24) and remove unbalance covers (23).

3. **Disassemble unbalances type XL and type XLs:**

Screw a long screw with the same thread into a tapped hole for the fastening screws (24) of the unbalance cover. Put a lever between the unbalance discs and this long screw. After loosening the locking nut (21), the unbalances can be removed from the shaft.



4. Remove bearing (10):
up to housing size 120: Remove circlip (40).
Starting from housing size 130: loosen screws (4) and remove flange (3). Remove circlip (40) from flange (3).
5. Replace both bearings (10) or remove old grease (e. g. with benzine) and smear the specified amount (see table) of new grease (according to the maintenance plan) evenly.
6. Assembly is carried out in the reverse order.
7. Tighten locking nuts (21) and screws (4, 16) to the specified tightening torque.

9 Troubleshooting



Observe the safety instructions in chap. Safety, starting on page 6.

Expertise and regulations

Troubleshooting of the vibrators may only be performed by regularly trained, authorised and qualified personnel. Work on the electrical system may only be carried out by a qualified electrician.

The qualified personnel has to work exclusively with tools suitable for the application.

In the case of unauthorised intervention in the NEG/NEH there is no longer any warranty claim.

Before any troubleshooting the NEG/NEH must be safely disconnected from the electrical mains. The procedure is as follows:

1. Switch off NEG/NEH.
2. Secure against unintentional switching on.
3. Determine that NEG/NEH are voltage free.
4. Earth and short-circuit.
5. Cover and fence off neighbouring live parts.

Trouble-shooting

Fault	Possible cause	Corrective action
Vibrator does not start or runs at too low speed	Phase interruption	Check fuse and connection cable, replace, if necessary.
	Mains voltage too low	Check mains voltage and cable cross-section and, if necessary, adjust or replace cable.
Vibrator speed drops under load	Wiring wrong	Check circuit diagram.
	Inadequate contact of a connection point	Check connections in the terminal box, tighten terminal plate nuts.
	Phase interruption	Check fuse and connection cable, replace, if necessary.
	Incorrectly dimensioned connection cable	Check cable cross section and replace cable, if necessary.
	Overload	Check setting of unbalance, reduce unbalances.
	Mains voltage too low	Check mains voltage and cable cross-section and, if necessary, adjust or replace cable.

Fault	Possible cause	Corrective action
Excessive heating of the vibrator	Wiring wrong / overload	Check circuit diagram.
	Mains voltage too low	Check mains voltage and cable cross-section and, if necessary, adjust or replace cable.
	Too much grease in bearings	Fill in correct amount of grease.
	No grease or not enough grease in bearings	Fill in correct amount of grease.
	Worn bearing or foreign objects in the bearing	Clean bearings, replace if necessary.
Vibrator hums	Phase interruption	Check fuse, mains voltage and connection cable. Correct mains voltage, replace fuse and/or cable, if necessary.
	Short-circuit between turns in the stator winding	Replace vibrator.
Circuit breaker fails when switched on	Phase interruption	Check fuse and connection cable, replace, if necessary.
	Overload	Check unbalance settings, reduce unbalance.
	Short circuit in winding	Replace vibrator.
High current consumption	Natural resonance range of vibration system	Measure current consumption, stiffen device.
	Bounce impacts, cracks in steel construction	Measure current consumption, reduce power of vibrator.
		Check steel structure for cracks, repair if necessary. Check fastening, tighten fastening screws, if necessary.
Breakage of the housing foot	Tensions in the housing	Replace vibrator. Check the flatness of the mounting surface. Tighten the fastening screws to the appropriate torque.
	Loose fastening	Replace vibrator. Tighten the fastening screws according to the maintenance schedule.
	Mounting surface not flat	Replace vibrator. Clean the mounting surface, grind or mill flat.

10 Spare parts and accessories

Ordering of spare parts

Please provide the following details when ordering spare parts:

1. type designation according to the type plate,
2. serial number according to the type plate,
3. description and position number of spare part, according to the overviews from page 26,
4. required amount.

Accessories

The following accessories are available for NEG/NEH:

Component	Description
Shim washers	Compensation for removed unbalance discs.
Fastening kit NBS	Recommended for secure and permanent fastening of the NEG/NEH.
Safety cables NSE	Prescribed in critical installation situations for additional protection against the NEG/NEH falling down.
Frequency converters	For frequency-controlled operation.

Further electrotechnical accessories on request.

Special models

The following special models are available on request:

- Versions for special voltages

11 Disposal

Disposal

	All parts of the NEG/NEH must be disposed of properly according to the material specifications.
	Do not dispose the electrical and electronic components of the NEG/NEH in the normal household waste, but in a special collection point for the environmentally friendly disposal of electrical equipment. Observe the national regulations for disposal.

Material-specifications

All parts of the NEG/NEH can be recycled.

Material	Part
Steel or stainless steel	Rotor, unbalances, flange, bearings, screws, washers, nuts, unbalance covers
Aluminium	Housing, type plate
Cast iron	Housing
Plastic	Seals, terminal box block
Copper with resin	Winding

12 Annex

The declaration of conformity can be found at: [www.**NetterVibration**.com](http://www.NetterVibration.com)